

COACH BUTTON





- It allows the coaches to take a timeout at any time by pressing the button during handball matches.
- It is placed on the right and left of the referee table.





WWW.LEDECH.COM